




# PATENT PRODUCT Grille Installation Instruction

Rev. 20201101

<b>Part#</b>	G65724C&J&S	<b>Application</b>	For 1995-2005 GMC Safari Van
--------------	-------------	--------------------	------------------------------

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	#1	Billet Grille	1	Stainless Steel	#3	U-Clip Nuts	4	8#
	#2	Truss Head Tapping Screws	4	8#x2"	#4	U Brackets	4	

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.	
3	Install the U-clip nuts onto the tabs as shown.	
4	Thread a Truss Head Tapping Screw in each nut welded to the grille. Secure billet grille using the U-Clip Nuts and U Brackets from the back side of the grille shell.	
5	Make sure the insert is centered and tighten the hardware.	
6	Reinstall the plastic shroud with the fasteners removed in Step 2.	
7	Installation completed.	

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!