




| | | | |
|-------|--------------|-------------|--|
| Part# | GR07FEG72A/H | Application | For 2003-2006 GMC Sierra 1500 / 1500 HD /2500 HD /3500 Without Logo Show/ 2007 GMC Sierra 1500 / 1500 HD/ 2500 HD /3500 Classic Style Without Logo Show/ 2003-2004 GMC Sierra 2500 Without Logo Show |
|-------|--------------|-------------|--|

| Parts List | Item | Part Name | QTY | Description | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-------------|------|-----------|-----|-------------|
| | 1 | Billet Grille | 1 | Aluminum | 3 | Screws | 4 | 8# × 3 " |
| | 2 | Lock Nuts | 4 | 8# | 4 | Flat Tabs | 4 | |

Install Notes: Overlay Replacement Drill Cut

| Step | Description | illustration |
|------|---|--|
| 1 | Identify the grille & hardware with parts list. |  |
| 2 | Open the hood, remove plastic rivets and bolts. Remove the fan shroud cover. Make sure the hand can reach the rear of the OEM grille shell. |  <p style="text-align: right;"> Fan shroud cover OEM grille shell </p> <p style="text-align: center;">Figure 1</p> |
| 3 | Overlay the billet on the OEM shell. | |
| 4 | Fasten the billet grille on the OEM shell with screws, flat tabs and lock nuts , | |
| 5 | Make sure the billet grille is in the center of the OEM shell, and then tighten all bolts. | |
| 6 | Reinstall the black plastic cover which was removed in step 2. | |
| 7 | Installation completed!!! |  |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!