


<b>Part#</b>	GR07FEG79J	<b>Application</b>	<b>07~10 GMC Yukon ( Bolton Logo Covered )</b>
--------------	------------	--------------------	--

<b>Parts List</b>	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	4	Screws	4	8# × 2 "
	2	Clip Nuts	4	8#	5	Longer "J" Hooks	2	
	3	Short "J" Hooks	2					

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	N/A
3	Test fit the grille over the factory grille. Use a slotted screwdriver to remover the fasteners holding the plastic radiator cover. Remove the six 10mm and two 7mm bolts along the top of the grille.	N/A
4	Place a block of wood or something similar between the top of the grille and the metal core support. This will allow access to the back of the grille. Slide the u-nuts onto the J hooks. Insert the machine screws into the tabs on the grille. Thread the short J hooks on the top screws and the longer J hooks on the bottom. Center the billet over the factory grille. Wrap the J hooks around the plastic bars and tighten the screws.	N/A
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	N/A
6	Reinstall the black plastic cover which was removed in step 2.	N/A
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!