


Part#	GR07FEG80C	Application	07~10 GMC Yukon Low Bumper (Towhook Covered)
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Screws	4	8# × 1 "
	2	Flat Nut	4	8#				

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove the plastic push-in clips that hold in the factory black plastic bumper insert. There are two in each of the outside opening near the tow hooks.	N/A
3	Remove the factory insert from the bumper. It is held in by clips around the perimeter of the part. It may be helpful to release the clips from the backside with your fingers or a screwdriver, and pull the insert straight out the front.	N/A
4	Center the billet insert in the opening and mark through the mounting holes of the grill onto the plastic support behind.	N/A
5	Remove the grill and drill a 1/8" hole on each of your marks.	N/A
6	Replace the grill and secure it with the supplied screws and clips with the clips on the backside of the plastic support.	N/A
7	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	N/A
8	Reinstall the black plastic cover which was removed in step 2.	N/A
9	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!