


|       |            |             |  |
|-------|------------|-------------|--|
| Part# | GR07FEH14C | Application | <b>For 2007-2013 GMC Sierra 1500 Between Tow Hook/ 2007-2010 GMC Sierra Denali Between Tow Hook/2007-2010 GMC Sierra 2500 HD / 3500HD Between Tow Hook</b> |
|-------|------------|-------------|--|

| Parts List | Item | Part Name     | QTY | Description     | Item | Part Name | QTY | Description |
|------------|------|---------------|-----|-----------------|------|-----------|-----|-------------|
|            | 1    | Billet Grille | 1   | Stainless Steel | 3    | Screws    | 4   | 6-32×2"     |
|            | 2    | Washers       | 2   |                 | 4    | Nuts      | 4   |             |

Install Notes: Overlay  Replacement  Drill  Cut

| Step | Description  | illustration  |
|------|--|---|
| 1    | Identify the grille & hardware with parts list.  |   |
| 2    | Use a screw driver to remove the license plate. The factory license plate mount is held to the bumper airdam by four Aluminum rivets.  |   |
| 3    | Test fit the grille into the bumper opening. The grille has two brackets welded to the back; use the hole in the brackets as a guide to mark the holes onto the air dam. Drill two 3/16" holes at each mark. |  |
| 4    | Insert a screw into each hole; from behind the air dam, secure each screw using the washers and lock nuts and tighten. Being careful to not over tighten.  |   |
| 5    | Installation completed.  |   |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!