

## PATENT PRODUCT Grille Installation Instruction

Rev. 141001

Part#	G	GR07FEI75H Applica		ation 2		2013-2015 GMC ACADIA						
	iet	Item	Part Na	ıme	QTY De		escription	Item	Part Name	QTY	Description	
Parts L		1	Billet Grille		1	6 Bi	llets	4	Truss Head Bolts	6	6-32×1"	
Faits L	ısı	2	Billet Grille		1 6 Billets		llets	5	Toggle Nut	6	6-32	
		3 Billet Grille 1 6 B			6 Bi	llets						
Install Notes: Overlay  Replacement ×								iII ×	Cut ×			
Step	Description							illustration				
1	Identify the grille & hardware with parts list.											
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille.Be sure the bolts are through the grille shell.											
4	Secure billet grille using Toggle Nuts from the back side of the grille shell.							66-32×2" Bolts and 66-32 Toggle Nuts				
5	Make sure the billet grille is centered and tighten the fasteners.											
6	Reinstall the black plastic cover which was removed in step 2.											
7	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!