

the fasteners.but do not over-tighten.

6

7

in step 2.

Installation completed!!!

Reinstall the black plastic cover which was removed

## Grille Installation Instruction

Rev. 150116

Part#	GR07FEI76J	Application	For 2013-2014 GMC Acadia Lower Bumper
-------	------------	-------------	---------------------------------------

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Stainless steel	3	Screws	4	8#x1 1/2"
	2	U-Nut	4	8#	4	Flat Tab	4	

Install	Notes: Overlay $\begin{bmatrix} \vee \\ \end{bmatrix}$ Replacement $\begin{bmatrix} \times \\ \end{bmatrix}$	Drill X Cut X		
Step	Description	illustration		
1	Identify the grille & hardware with parts list.			
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.			
3	Install the u-nuts onto the flat tabs.			
4	Center the billet grille onto the factory grille. Insert screw through the weld tab hole on the billet grille cure the grille with the 8# screws and flat Tab(with U-clip nuts). Be sure the screws are through the OEM grille shell.			
5	Make sure the billet grille is centered and tighten the fasteners but do not over-tighten.	N/A		

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

N/A

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!