

Grille Installation Instruction

Part#	GR07FFC26F/W		Application		For	For 2015-2018 GMC Sierra 2500 / 3500				
	lter	n Part	Name	QTY	Descrip	otion	ltem	Part Name	QTY	Description
Parts Li	1	Billet G	Billet Grille		Aluminum		5	Mounting bracket hooks	2	
	<b>st</b> 2	Studs	Studs		6-32X 1 <b>″</b>		6	Self drilling screw	2	#8 3/4 "
	3	Flange	Flange Nuts		6-32		7	Flat nut	2	#8
	4	Plastic	Plastic Washers		6#					
Install N	lotes: (	Overlay	_√ R	eplace	ment	×	Drill	$$ Cut $\times$		
Step		Desc	ription		illustration					
	Identify the grille & hardware with parts list. Assemble billet grille as shown.					(9) M4-15 Bolts (9) M4-15 Bolts (9) M4 Nylon lock nuts				
							ø	l B		
2	OEM gr	ille / front		n vehicl	e. This wil	l allow	access	pop hood, remove the bl to the rear of the grille s stallation.		
3	OEM gr access Attach th	ille / front the rear, r	panel) from emove the uts to each	m vehicle grille sl	e. This wil	l allow	access	to the rear of the grille s		
3	OEM gr access Attach th the moun Place th	ille / front the rear, r ne two U Nu nting brack	panel) from emove the uts to each ets.(Fig 1)	n vehicle grille st side of side of th	e. This will hell and re Fig 1	l allow eattach	access after ins	to the rear of the grille stallation.	shell. If yo	u are still unable to
3	OEM gr access Attach th the mount Place th a guide. Thread	ille / front the rear, r ne two U No nting brack ne bracket Secure c a stud in o	panel) from emove the uts to each ets.(Fig 1)	n vehicle grille st side of side of th of the p relded to	e. This will hell and re Fig 1 he bumper plastic with the grille.	l allow eattach	ing. Drill at nut ar	to the rear of the grille stallation. Fig 2 a 3/16 " hole through th	shell. If you	u are still unable to
3 4 5	OEM gr access Attach th the mount Place th a guide. Thread plastic v	ille / front the rear, r e two U Nu nting brack secure c a stud in e vashers a	panel) from emove the uts to each ets.(Fig 1)	side of the prelded to nuts from	e. This will nell and re Fig 1 Fig 1 he bumper plastic with the grille. n the back	I allow eattach	ing. Drill at nut ar the grille of the Ol	to the rear of the grille stallation. Fig 2 a 3/16 " hole through the a screw bract into place a against the OEM grille	shell. If you	u are still unable to
3 4 5 6	OEM gr access Attach th the mount Place th a guide. Thread plastic v Make su	ille / front the rear, r he two U No hting bracket Secure of a stud in o vashers a ure the gri	panel) from emove the uts to each ets.(Fig 1)	side of the preded to nuts from	e. This will hell and re Fig 1 Fig 1 he bumper plastic with the grille. In the back	I allow eattach open of the fl . Hold c side of he fast	ing. Drill at nut ar the grille of the Ol eners.	to the rear of the grille stallation. Fig 2 a $3/16$ " hole through the screw bract into place a gainst the OEM grille EM grille shell.	shell. If you	u are still unable to

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!