

Grille Installation Instruction

Rev. 190101

Part#	GR07FFD16A/H Application For 2				For 20	2017-2019 GMC Acadia Lower Bumper					
Parts	3 1	Item Part Name 1 Billet Grille		QTY 1 /	Description Aluminum		Item 3	Part Name Bolts	QTY 6	Description 6-32x1.5"	
List	2	2 Toggle nuts		6 6#							
Install Notes: Overlay Replacement											
Step	Description					illustration					
1	Identify the grille & hardware with parts list.										
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.										
3	Hold the grille against the OEM grille shell, center and mark holes for drilling. Remove billet grille and drill holes according to your mark.										
4	Place screws through welded aluminum tabs on front of the grille. Be sure the bolts are through the OEM grille shell. Secure the grille using toggle nuts from the back side of the OEM grille shell.						Mark and drill 4 holes				
5	Make sure the billet grille is centered and tighten the fasteners.										
6	Reinstall the black plastic cover which was removed in step 2.										
7	Installation completed!!!						910				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!