

## PATENT PRODUCT Grille Installation Instruction

Rev. 181201

Part#		GR07FFD18 C/S/J		Аррі	lication	For 2	For 2018-2019 GMC Terrain Nor for Denali Main Upper					
		Item	Part Name		QTY	Description		Item	Part Name	QTY	Description	
Parts L	ist	1	Billet Grille		1	Stainless steel		3	Flat Tabs	6		
		2 Screws			6 8# ×2.5"			4	U-Nuts	6	8#	
Install I	Note	es: Ov	verlay   √	Re	eplacem	nent ×	Dri	ill V	Cut	×		
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.											
3	Hold the billet grille against the OEM grille shell, center and mark holes for drilling. Remove billet grille and drill holes according to your mark.											
4	Place screws through the welded aluminum tabs on the grille. Hold the billet grille up to the opening of the factory shell. Secure billet grille using the flat tabs and U-nuts from the back side of the OEM grille shell.							Mark and drill 1 hole				
5	Ма	Make sure the grille is centered and tighten the fasteners. But not over-tighten.										
6	Re	Reinstall the black plastic cover which was removed in step 2.										
7	7 Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!