

## Grille Installation Instruction

Rev. 130701

also mais seculis me										Rev. 130701	
Part#		GR07HEC70S		Appli	Application For 2		2001-200	)6 GM	C Yukon Denali C Yukon Denali C Sierra Denali		
		Item	Part Name		QTY	Description		Item	Part Name	QTY	Description
Parts L	ist	1	Billet Gril	е	1		Stainless steel		Flat Nuts	4	8#
		2	Screws		4	8×3/4"		4	/	/	/
Install Notes: Overlay    X  X  X  X  X  X  X  X  X  X  X  X								II ×	Cut ×		
Step	Description						illustration				
1	Idei	ntify the	grille & ha	rdware wi	th parts li	st.		_	•		
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.  Attention: Must remove factory tow hooks from your vehicle for this billet bumper grille. BTW, remove the factory plastic insert if does have.										
3	Center the billet grille into the opening of the factory grille shell. Secure the screw to the threaded holes on the front of the grille.Be sure the screws are through the OEM grille shell.						N/A				
4	Secure billet grille using the flat nuts from the back side of the OEM grille shell.						N/A				
5	Make sure the billet grille is centered and tighten the fasteners.						N/A				
6	Reinstall the black plastic cover which was removed in step 2.						N/A				
7	Installation completed!!!						N/A				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!