

Τ

Part#	GR07HED72A			Applicatio	' 03~06 GN		MC S	ierra Co	enter Airdam –	1pc C	Cover 2 Holes
		Item	Part Name		QTY	TY Description		ltem	Part Name	QTY	Description
Parts L	int	1	Billet Grille		1	Aluminum		4	Hex Bolts	4	1/4″ -20×3/4″
Parts L	.ist	2 "Z" I		Bracket Tabs	2			5	Lock Washers	4	1/4 ″
		3	Flat Wa	ashers	4	1/4″		6	Nuts	4	1/4″-20
Install Notes: Overlay 🗸 Replacement 🗵						nt ×	Drill × Cut ×				
Step	Description						illustration				
1	Identify the grille & hardware with parts list.									/	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.										
3	Fasten this side of the brackets to the factory holes on top of the steel bumper. Use the hardware to fasten the brackets to the billet insert here							<u>+</u>	Fasten this holes on to Use the hardware to fasten the br	op of the steel bu	2
4	Secure billet grille using the nuts from the back side of the OEM grille shell.						N/A				
5	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.						N/A				
6	Reinstall the black plastic cover which was removed in step 2.						N/A				
7	Installation completed!!!						N/A				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!