

Item

Part Name

QTY

Grille Installation Instruction

Rev. 150116

Description

QTY

Part# | GR07HED72H | Application | 03~06 GMC Sierra Center Airdam – 1pc Cover 2 Holes

Item

Part Name

Description

	ŀ	1	Dillat C	سااات		4	A luma in		1		Lley Delte	1	1/4" -20×3/4"
Parts List		1	Billet Grille			1	Aluminu	m	4		Hex Bolts	4	
		2	"Z" Bracket Tabs			2			5		Lock Washers	4	1/4"
		3	Flat Washers			4	1/4″		6		Nuts	4	1/4" -20
Install Notes: Overlay Replacement ×							nt ×	Dı	rill [×	Cut ×		
Step	Description							illustration					
1	Identify the grille & hardware with parts list.								F				
2	OE	√ grille	/ front p	anel) fro		le. This	on top of will allow						
3	Fasten this side of the brackets to the factory holes on top of the steel bumper. Use the hardware to fasten the brackets to the billet insert here									T	Easten this holes on to	op of the steel b	
4	Secure billet grille using the nuts from the back side of the OEM grille shell.							N/A					
5	Mak the	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.											
6		Reinstall the black plastic cover which was removed in step 2.											
7	Installation completed!!!												

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!