



PATENT PRODUCT


Grille Installation Instruction

Rev. 190201

Part#	GR07HEJ12 P/Q	<i>Application</i>	For 1994-1999 GMC Suburban Composite Plastic Lights/1994-1999 GMC Yukon Not For Denali/1994-1998 GMC C/K Pickup with Stacked Lights Main Upper
--------------	------------------	--------------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	4	Truss Socket Tapping Screws	4	10×3/4"
	2	Hole Tabs	2		5	Truss Head Tapping Screws	3	10×3/4"
	3	Nut	7	10#	6	Slotted Hex Head Tapping Screws	2	1/4" ×3/4"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	3
4	Remove four screws retaining each parking light. Unplug and remove lights.	5
6	Carefully saw out the factory plastic grille (webbed air intake section) with a hacksaw blade and handle without cutting into the rim of the shell.	7
8	Mark and drill the shell where the three uprights touch the underside of the top of the shell and install screws.	9
10	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
11	Reinstall the black plastic cover which was removed	
12	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!