

Grille Installation Instruction

Rev. 200101

Part#	GR07	GR07LEA56L		Application		For 2003-2006 GMC Sierra 1500 (Not For C3 Model) Logo Covered						
	Item	Part Name		QTY	Description		Item	Part Name	QTY	Description		
Parts Li	1 st	Rivet Grille		1	Stainless	steel	4	90° L Bracket	5	1		
i aits Li	2	2 Lock Nut		22 0.190-24			5	70° L Bracket	6	/		
	3	3 Bolt		11	0.190-24	× 1/2"						
Install Notes: Overlay X Replacement Drill Cut Cut												
Step		cripti	on		illustration							
1	Identify the grille & hardware with parts list.											
	Pop hood, start by removing the plastic clips that secure the grille cover as shown. Then, remove the plastic grille cover. Next											
2	remove the bolts along the top of the grille shell.											
3	Unfasten the grille shell clip located in signal lamp area it may help to push it from the backside. Unclip the grille shell. The entire grille shell can be removed. The grille ribs will be cut out. Using a saw cut the stock plastic grille ribs out, and remove center section.											
4	The grille hips will be cut out. Oshig a saw cut the stock plastic grille hips out, and remove center section.											
5	Attach the	Attach the five 90° L brackets to the screws on the top of the grille, secure them with lock nuts.										
6	Attach the six 70° L brackets to the screws on the bottom of the grille, secure them with lock nuts.											
I _												

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!

Position the grille onto grille shell cavity.



Grille Installation Instruction

Rev. 200101

Part#	GR07LEA56L	Application	For 2003-2006 GMC Sierra 1500 (Not For C3 Model) Logo Covered					
8	Mark locations for drilling on the shell through the holes of L brackets. Then drill holes on those locations.							
9	screws through the	ne shell by inserting t abs of L brackets an ecure them with lock	d Sie					
10	Reinstall the plastic shroud with the fasteners removed.							
11	Installation completed.							

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!