








Part#	GR08FFE03A/H	Application	For 2007-2008 Honda Element SC Not For EX/LX
-------	--------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Aluminum	3	Flat Nuts	6	8#
	2	Truss Head Tapping Screws	6	8#X2"	4	Flat Tabs	6	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration	
1	Identify the grille & hardware with parts list.		
2	Pop hood, Remove the plastic clips on the top side of the upper radiator cover.(Fig 1)		
3	Remove the upper radiator trim panel.(Fig 2)		
4	In order to remove the factory upper grille. You will need a stubby phillips screw driver or a angled screw driver as shown.(Fig 3)		
			
5	Remove the six phillips screws that hold the factory upper grille in place.The screws are located on the back side of the grille.(Fig 4)		
6	Once the screws are removed. Unclip the plastic grille fastners simply push down on clips.Upper grille can now be removed.(Fig 5)		
			
7	Place one screw through each of the welded tabs on the billet grille. Be sure the screws are through the OEM grille shell. Fasten grille in place using a flat tab and nut from the back side. (Fig 6)		
8	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.		
9	Reinstall the upper OEM grille and upper radiator trim panel which was removed.		
10	Installation completed!!!		

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!