


<b>Part#</b>	<b>GR08FGA30A/H</b>	<b>Application</b>	<b>For 2006-2008 Honda Pilot</b>
--------------	---------------------	--------------------	----------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	4	Screws(#6 head)	4	#8x1"
	2	U-Nuts	4	#8	5	J Hooks	2	2"
	3	J Hooks	2	3/4"				

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Slide the u-nuts onto the J hooks. Insert a screw into each tab welded to the billet. Thread the J hooks onto the screws.	
4	Center the billet into the opening; Wrap the longer J hooks around the bottom of the bumper opening. Secure the short J hooks to the top.	
5	Turn the nuts so that it is vertical, and tighten. But not over-tighten!	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!