

## **PATENT PRODUCT** Grille Installation Instruction

Rev. 150116

Part#	GR08FGA		GA34J	A34J Applie		For 06~0 Grille	Accord Cou	ipe – I	Low B	umper Billet		
		Item	Part Name		QTY	Descriptio	n It	tem	Part Name		QTY	Description
Parts Li	ist	1	Billet Grille		1	Stainless steel		3	Powder Coated Brackets		2	
		2 Nuts			4	6-32		4	Bolt		4	6# X 2″
Install N	lote	es: Ov	verlay	$\checkmark$	Replac	ement X	D	Drill	× Cut	×		
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
3	Install the fully threaded studs into the backside of the billet insert.											
4	Center the billet grille into the opening of the factory grille shell. Place the powder coated brackets over the fully threaded studs. Be sure the bolts are through the OEM grille shell.											
5	Secure the billet grille to the vehicle using nuts.					sing the k-lock	N/A					
6	Make sure the billet grille is centered a the fasteners.					and tighten	N/A					
7	Reinstall the black plastic cover which in step 2.Installation completed!!!					was removed	N/A					

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!