

Grille Installation Instruction

Rev. 191001

AUTO	PARTS SPECIALIS	/ INC		<u> </u>		- Canaci	<u> </u>	1011 4011011		INGV	. 191001
Part#	H768	801T/H	H Application			r 2010-2013 Acura MDX					
	Item	Part	Part Name		Description		Item	m Part Name		QTY	Description
	1	Mesh Grille		1	Stainless steel		5	Top Mounting Plate		1	
Parts List	rts List 2 K-Lock N		ıts 12		6-32		6	Emblem Mounting Plate		1	
	3	Double Faced Tape		1			7	Lower Mounting Plate		1	
	4	Double Fa	ced Tape	4	#8×1	/2"	8	Black Washers		2	
Install Notes: Overlay × Replacement √ Drill √ Cut ×											
Step		Des	cription					illu	stration		
	Identify the grille & hardware with parts list.										
	Remove the radiator support cover by lifting straight up to release the clips and remove the cover (to be reinstalled).										
3	Remove	the top 10	mm faste	ners ret	aining	the grille	(one pe	er side).			
Apply several of masking tape around the perimeter of the factory grille to protect the painted bumper cover during the following grille removal procedure.											
5	Use a push pin release tool to pry down on the center of the lower push pins, separating the grille from the bumper cover. The push pins are installed inverted. Carefully unclip one tab at a time, working your way from one side to the other.										

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 191001

Part#	H76801T/H	Application	For 2010-2013 Acura MDX				
	7		Reflected image				
6	Close-up of the inverted installed factory push fastener showing how to pull out the Center portion of the pin.						
7	Once the lower push fasteners are removed, pull the grille forward and remove it from the bumper cover.						
8	Remove the factor	ory Acura emblen	n from the factory grille. The emblem is secured with two small phillips				
9	Install the supplied double faced tape to the back of the factory emblem and adhere it to the supplied emblem						
	mounting plate (as show).						
10	Using the supplied large black plastic washers and the factory phillips screws; install the emblem onto the mesh grille, making sure the emblem is perfectly centered in the recess.						
	8						
11	Apply masking tap	Apply masking tape to the painted bumper cover 1/4" inside the grille opening.					
12	Tape in 1/2" from scotch brite pad to		headlight assemblies that will be visible through the mesh grille and use a astic lenses.				

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



Grille Installation Instruction

Rev. 191001

	UTO PARTS SPECIALIST INC.			Nev. 191001			
Part#	H76801T/H	Application	For 2010-2013 Acura MDX				
13	Paint everything inside the grille opening with flat or semi-gloss black paint that would be visible through the mesh grille, including the portions of the headlights scuffed in the previous step.						
		10 -					
14	Align the mesh grille into place and reinstall the lower factory push pins removed in step 4.						
15	Once the grille is flush with the bumper cover, use a 1/16" drill bit to drill through the holes in the lower mounting plate and through the bumper cover.						
16	Install the supplied the bumper cover.	d #8×1/2" Black	Truss Head Screw (one each side) to secure the	e lower mounting plate to			
17	Reinstall the 10mm hex head bolts and the factory plastic push pins removed in step 2						
18	If the plate is not tight against the core support, push down on the top plate until it is tight, then drill a $1/8$ " hole through the hole shown and install a $48 \times 1/2$ " Black Truss Head Screw (each side as needed).						
19	Reinstall the radiat	tor support panel	cover, reusing the factory hardware removed in s	tep 2.			
	15 Jan 19		16	18			
20	Installation comple	eted!!!					

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!