

Grille Installation Instruction

Rev. 150116

Part# | GR08HGA15V | Application | O5-08 Honda Ridgeline 2 Side PCS Overlay Lower Bumper

		Item	Par	t Name	QTY	Descrip	tion	Item	Part Name	QTY	Description
Parts L	ist	1 Billet Grille		2	Aluminum		3	Phillips Screws	6	8# × 1 "	
		2	Speed	Clips	6	8#					
Install Notes: Overlay						nent ×	Drill ✓ Cut ×				
Step	Description						illustration				
1	Inspect product and check components with items listed above.						EU	*****			
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.										
3	Remove the factory grille shell and set aside.						N/A				
4	Center the billet grille into the factory grille shell opening and mark three spots through holes of the tabs on each side of the grille shell and drill holes on the two sides of the grille shell.										
5	Re-center the billet grille into the factory opening and secure using the speed clips and phillips screws.										
6	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.						N/A				
7	Attach the front fascia to the vehicle using the factory hardware .						N/A				
8	Installation completed!!!						N/A				

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!