


<b>Part#</b>	GR08HGA16C	<b>Application</b>	For 05~08 Honda Ridgeline Low Bumper (1 Center PC)
--------------	------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Stainless steel	3	Slotted Studs	4	6# 2"
2	Kep Nuts	4	6#	4	Powder Coated Brackets	4		

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood of the vehicle, and then remove the plastic filler panel.	N/A
3	Once the filler panel is removed, you can now access the back of the grille. Remove the Phillips screws that hold the factory grille shell into place.	N/A
4	Remove the factory grille shell from the vehicle.	N/A
5	Secure the studs into the back side of the billet grille.	N/A
6	Place the billet grille into the opening, of the vehicle, being sure that the studs go through the factory mounting holes.	N/A
7	Once the billet grille is place into the opening be sure that the billet grille is center, and make any adjustments as needed.	N/A
8	Place the powder coated brackets over the studs, and then secure using the kep nuts.	N/A
9	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!