

Installation completed!!!

8

Grille Installation Instruction

Rev. 180401

Part#	GR08HGA29A&H	Application	For 2006-2008 Honda Pilot
-------	--------------	-------------	---------------------------

		Item	Part Name	QTY	Description	Item	Part Name	QTY	Description			
Parts L	ict	1	Billet Grille	1	Aluminum	4	Z Extension Brackets	2				
raits L	.131	2	U-Nuts	8	8#	5	Truss Head Tapping Screws	8	8# × 1 "			
		3	L Brackets	2								
Install Notes: Overlay X Replacement V Drill X Cut X X X X X X X X X												
Step	Description					illustration						
1	Identify the grille & hardware with parts list.											
2	Remove the radiator cover from the vehicle. There are five plastic fasteners hold the grille to the bumper cover along the bottom of the grille. Once these are unfastened the grille can be removed. If you are installing the bumper billet; install at this time.											
3	Center the billet into the opening; note the mounting brackets on the bottom. Slide a u-nut over the bumper cover holes aligned with the lower mounting tabs. On top; install a u-nut in each corner.											
4	Attach the Z shaped extension brackets with the screws .Install a u-nut onto the other end of the brackets. Center the grille; use four screws to attach the lower mounting brackets and corner tabs to the extension brackets (it may be necessary to slightly bend the brackets with a pair of pliers to achieve the proper alignment).											
5	Re- install the radiator cover. Use the remaining u-nuts and screws to attach the L shaped extension brackets on top of the billet.											
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.											
7	Sec	Secure the brackets to the radiator cover using the plastic push-in fasteners.										

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!