


Part#	<b>GR09GFH06T&amp;H</b>	Application	<b>For 2010-2012 Subaru Legacy</b>
-------	-------------------------	-------------	------------------------------------


Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	4	Torx T-10 Pin Head Screws	4	6#-X1/2 "
	2	Lower Grille Tape Location Template	1		5	Lower Grille Hole Location Template	1	
	3	Washers	9		6	ESNA Half Nuts	9	6#-32

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood and carefully apply several layers of masking tape to the painted lower grille opening.	
3	Cut out and align the lower grille tape location template, taping it into place. Cut the supplied foam tape to fit inside the rectangular notches in the template.	
4	Cut out and align the lower grille hole location template, taping it into place. Use an awl or similar pointed tool to mark the center of the hole.	
5	Remove the template and drill through the mark made in the previous step with a 5/16" drill bit.	



Align the lower mesh grille assembly into place, then reach through the upper grille opening to install the supplied washer and nut onto the center lower mounting stud. Tighten only until the washers no longer rotate but **DO NOT OVERTIGHTEN**. Overtighten will indent the surround at the stud location.



7 Remove any Protective liner that could get caught under the torx pin head screws. Make sure that the lower mesh grille is perfectly centered in the factory grille opening. The torx pin head screws will tap into the bumper cover through the mounting tabs. **DO NOT OVERTIGHTEN** or you will strip out the mounting holes.

8 Installation complete.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!