

## Grille Installation Instruction

Rev. 180901

Part#	GR11FFG14A/H	Application	For 2005-2008 Kia Sportage
-------	--------------	-------------	----------------------------

	It	em	Part Name	QTY	Description	Item	Part Name	QTY	Description			
Parts Lis	-4	1	Billet Grille	3	Aluminum	4	Truss Head Screws	4	8×2.5″			
Parts Li		2	Flat Tabs	4		5	Truss Head Screws	4	8×1.5″			
		3	U-Clips	8	8#							
Install Notes: Overlay    Replacement    Drill    Cut												
Step	Description					illustration						
1	Identify the grille & hardware with parts list.											
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.											
FOR CENTER BILLET GRILLE:												
3	Place one screw through each of the welded tabs on the billet grille.											
4	Place a U-clip nut over the hole on the flat tab.											
5	Where the screws come through the grille shell, place a tab in align with the screw and tighten. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center. <b>DO NOT OVER TIGHTEN SCREWS.</b>											
FOR SIDE BILLET GRILLES:												
6	Drill 3/16" hole on the 4 sites marked on the shell.											
7	Tighten grille with Phillips screw and clips provided.											
8	Repeat the process on the right opening of the grille shell.											
9	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.											
10	Reinstall the black plastic cover which was removed in step 2.											
11	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!