

Grille Installation Instruction

Rev. 190501

Part#		K66715A/H		For	For 2009-2010 Kia Borrego							
		Item	Part Na	me	QTY	TY Description		Item	Part Name	QTY	Description	
Parts List		1	Billet Grille		1	Aluminum		3	Toggle Nut	5	6# -32	
		2	Bolt		5	6#-32x1"						
Install	Not	Notes: Overlay Replacement					D	rill V	Cut	×		
Step	Description					illustration						
1	Identify the grille & hardware with parts list.									3		
2	Optional: remove the plastic cover on the bottom of the OEM front bumper, which will allow access to the rear of the OEM grille											
3	Hold the billet grille against the OEM grille shell, center and mark holes for drilling. Remove billet grille and drill holes according to your mark.											
4	Center the billet grille onto the OEM grille. Place screws through the welded aluminum tabs on the grille.											
5	fact	ory sh	oillet grille u iell. Thread EM grille ho	n the to	oggle nu			Mark and drill 4 holes Toggle Nut				
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.											
7	Reinstall the black plastic cover which was removed in step 2.											
8	Installation completed!!!							161				

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!