



Grille Installation Instruction

Rev. 190601

Part#	GR11FFG17A/H	Application	For 2010-2011 Kia Forte Not For SX And Koup
-------	---------------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Aluminum	3	Truss Head Screws	4	6-32×1.5"
2	Toggle Nuts	10	6#	4	Truss Head Screws	6	6-32×1"	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	

FOR CENTER BILLET GRILLE:

1	Remove the grille from the box.
2	Place 6-32×1.5" screws through the welded aluminum tabs on the grille, and attach a toggle nut on the end of each screw.
3	Hold the billet insert up to the opening of the factory shell, make sure that it is centered in the grille shell, and push in the toggle nut past the factory grille honeycomb.
4	Turn the toggle nut so that it is vertical, and tighten. But not over-tighten!
5	Repeat steps three and four for the remaining three welded tabs on the billet grille.

FOR SIDE BILLET GRILLES:

1	Drill 3/16" hole on the 6 sites marked on the shell.
2	Place 6-32×1" screws through the welded aluminum tabs on the grille, and attach a toggle nut on the end of each screw.
3	Tighten grille with screws and toggle nuts provided.
4	Repeat the process on the right opening of the grille shell.
5	Installation Complete ! ! !

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!