




<b>Part#</b>	<b>GR11HFH30A/H</b>	<i>Application</i>	<b>For 2011-2016 Kia Sportage</b>
--------------	---------------------	--------------------	-----------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum				

Install Notes: Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood. Remove the fasteners holding the upper plastic shroud where the factory grille is.	
3	Remove the fasteners retaining the factory grille to remove the grille.	
4	Install the billet grille using the factory grille fasteners, using the factory holes.	
5	Make sure the billet grille is centered and tighten the fasteners.	
6	Reinstall the upper plastic shroud which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!