




Grille Installation Instruction

Rev. 190101

Part#	GR12HEJ56A/H	Application	For 2003-2006 Lincoln Aviator
-------	--------------	-------------	-------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	2	Screws	4	10# X 1"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Open the hood and pull out on the factory radiator cover. (Note: Cover has no nuts or bolts, the clips slide in and out and does not require any tools.)	
3	Mask off area around bumper opening in order to prevent scratching and gouging.	
4	Place billet grille into bumper opening. Center and hold in place. Reaching through the opening that was covered by the radiator cover. Mask and remove the grill.	
5	Drill four holes with a 1/8 inch drill bit.	
6	Screw in the four screws provided in kit.	
7	Remove masking tape and wipe down.	
8	Make sure the grille is centered and tighten the fasteners. But not over-tighten.	
9	Reinstall the factory radiator cover which was removed in step 2.	
10	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!