

PATENT PRODUCT Grille Installation Instruction

Rev. 20210901

Part#	M66261C&J&S Application					For 2003-2005 Mazda Mazda 6 Only for s Wagon/s Sport Wagon/i Sport Sedan					
		ltem	Par	t Name	QTY	Desci	ription	ltem	Part Name	QTY	Description
Danta L		#1	Billet Grill	е	1	Stainless	Steel	#4	Truss Head Screws	4	6-32×1.5"
Parts Li	<b>#</b> 2		Washers		4	6#		#5	Truss Head Screws	4	6-32× 2"
		#3 Toggle Nuts		uts	4 6#			#6	Nylon Lock Nuts	4	6-32
Install Notes: Overlay $\checkmark$ Replacement $\times$ Drill $\checkmark$ Cut $\times$											
Step	Description					illustration					
1	Identify the grille & hardware with parts list.										
2	2 Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.										
3		Insert the Screw into the weld tab hole from front side of the billet grille.									
4	Hold the billet grille against the OEM grille shell, center and mark (4) holes for drilling. Remove billet grille and drill holes according to your mark.										
5	<ul> <li>Center the billet grille onto the OEM grille. Press &amp; insert the toggle nuts on to the rear of the OEM grille through the gap.</li> <li>For (2) pieces on both sides, thread a 6-32×2" Truss Head Screw in each nut welded to the grille. From the rear, place a a washer on each screw. Now thread a nut on each screw.</li> </ul>										
(4) 6-32×2" Truss Head Screws (4) Washers (4) Nylon Lock Nuts Drill Drill (4) Toggle Nuts (4) 6-32×1.5" Truss Head Screws											

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!



## PATENT PRODUCT Grille Installation Instruction

Rev. 20210901

Part#	M66261C&J&S	Application	For 2003-2005 Mazda Mazda 6 Only for s Wagon/s Sport Wagon/i Sport Sedan				
6	Make sure the insert is centered and tighten the hardware.						
7	Reinstall the plastic shroud with the fasteners removed in Step 2.						
8	Installation completed.						

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!