

**PN: GR13GFB29T**

**06~07 Mazda Speed 6 – Low Bumper Stainless Steel Mesh Grille**

Hardware

4-- 6-32×1" Screws	10 -- 6-32 Nylon Lock Nuts	
10-- Flat Tabs	2-- 6-32×3" Screws	10-- Washers

NOTE: Instruction for billet grille also applies to stainless steel grille.

- (1) Remove the grille from the box. Test fit the grille to make sure that it fits in the shell properly. Make sure the grille is centered.
- (2) Thread a short screw in each nut welded to the middle grille. Thread a long screw in each nut welded to the side grille. From the rear, place a tab on each screw. Now thread a nut on each screw.
- (3) Make sure the insert is centered and tighten the hardware.

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!