

5

6

7

in step 2.

side of the OEM grille shell.

Installation completed!!!

Make sure the billet grille is centered and tighten

Reinstall the black plastic cover which was removed

the fasteners.but do not over-tighten.

Grille Installation Instruction

Rev. 150116

Part#	GR14FEB68C	Application	2005-2006 Nissan Altima Only For SET Model Lower
			Bumper

			, ippineau	Bu	mper						
		Item	Part Name	QTY	Descrip	tion	Item	Part Name	QTY	Description	
Parts L	ist	1	1 Billet Grille		1 Stainless ste		3	U-Clip Nuts	4	8#	
		2 Flat Tabs		4			4	Screws	4	8×1″	
Install I	Note	es: Ov	∕erlay	eplacer	ment ×	C	orill >	Cut ×			
Step		Description					illustration				
1	Ide	Identify the grille & hardware with parts list.									
2	OE	M grille	remove the black pl / front panel) from v he rear of the grille s	ehicle. Th		N/A					
3	grill the	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille.Be sure the bolts are through the OEM grille shell.									
4	Sec	cure bill	et grille using the nu	its from th	ne back	N/A					

N/A

N/A

N/A

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!