

Grille Installation Instruction

Rev. 150116

Part# | GR14FEC59A | Application | O0-01 Nissan Pathfinder Honeycomb Only Logo Covered

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	4	Nylon Lock Nuts	4	6-32
	2	"J" Hooks	4		5	Truss Head Screws	4	6-32x2"
	3	Flat Washers	4	6#				
Install Notes: Overlay Replacement								

Install	Notes: Overlay $\begin{bmatrix} \sqrt{} \end{bmatrix}$ Replacement $\begin{bmatrix} \times \\ \end{bmatrix}$	Drill X Cut X		
Step	Description	illustration		
1	Identify the grille & hardware with parts list.			
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.			
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille.Be sure the bolts are through the OEM grille shell.	N/A		
4	From the rear of the shell, place a "J" hooks onto the screws. Next install a washer and lock nut. Hand-tighten the lock nuts; Do not tighten the screws yet.			
5	Re-center the billet over the opening. Adjust the "J" hooks so they wrap around the back of the inner grille mesh. Use a Phillip screwdriver and wrench to tighten the screws if desired, re-install the factory logo using a high quality double-sided tape.	N/A		
6	Installation completed!!!			

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!