



Grille Installation Instruction

Rev. 150116

Part#	GR14FED12S	Application	For 04~07 Nissan Armada / Titan Logo Show (3 pcs)
-------	------------	-------------	---

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Stainless steel	3	Truss Head Screws	8	10-24×2"
	2	Mounting Clips	8		4	Lock Nuts	8	10-24

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Remove the stock grille shell by using a straight blade screwdriver and turning the Plastic Hold Downs a quarter turn to release. There are (4) across the top and (3) on the bottom and (2) on the left and right side. Step 2 will show the locations of the left and right release screws that are not visible in the lower corners of the stock grill.	
4	On the lower left and right outsides of the grille shell there is (1) quarter turn screw that can be reached by going thru the lower opening on the side of the grille as shown above.	
5	Place masking tape on all of the painted and or chrome surfaces to protect the grille from scratches during install. Next remove the plastic shroud covers on the outer left & right side of the stock grille shell. You may have to use a flat blade screwdriver to release.	
6	When installing (Logo Covered or No Logo), you will need to remove the Nissan emblem by using a wide flat blade screw driver or putty knife to pry it off. The emblem is held on by double sided tape. Insert the billet grille and center into the openings. Use the supplied 10-24×2" Bolts & Nuts for all locations of the billet grille. On the side grilles for top locations only. Secure all bolts, being careful not to over tighten. As shown above.	
7	If there are any of the quarter turn screws remaining on the vehicle. You need to remove these and place them back on the stock grille shell. Make sure the Head of the plastic quarter turn screw ins square and insert, then squeeze and make a quarter turn back in place.	
8	Next replace the plastic covers that were removed in step 3.	
9	Make sure the billet grille is centered and tighten the fasteners.but do not over-tighten.	
10	Next simply re-install the stock grille shell by lining up the plastic quarter turn screws with their original stock locations and slightly pushing them back in place.	
11	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!