

Grille Installation Instruction

Rev. 180301

Part#	GR14FED12V	Application	For 2004-2007 Nissan Armada / Nissan Titan With Logo Show
-------	------------	-------------	--

		Item Part Name QTY		Description		Item	Part Name	QTY	Description			
Parts L	ist	1	Billet Grille	3	Aluminum		3	Truss Head Screws	8	6#-32x2"		
		2	Flange Nuts	8	6#-32		4	Flat Tabs	8			
Install Notes: Overlay						Drill × Cut ×						
Step	Description					illustration						
1	Identify the grille & hardware with parts list.											
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.											
3	Position the Billet Grille onto grille shell cavity.											
4	Loosely attach the Billet Grille by holding the Flat Tabs behind factory grille shell and inserting the Screws (from the front) through the Billet Grille holes and Flat Tabs, secure them with Flange Nuts provided.											
5	Make sure the billet grille is centered and tighten the fasteners.											
6	Rei	nstall t	he black plastic c	over which	h was remo	oved in s	step 2.					
7	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!