

PATENT PRODUCT Grille Installation Instruction

Rev. 150116

Part#		GR14FED36J		Application		For 2	For 2000-2001 Nissan Xterra					
		ltem	Part Name		QTY	Description		ltem	Part Name	QTY	Description	
Parts L	ist	1	Billet Grille		4	Stainless steel		3	Truss Head Screws	4	8×1″	
		2	Flat Nuts		4							
Install N	lote	s: Ov	verlay 🗸	Re	eplacen	ment X Dr		√	Cut ×			
Step	Description						illustration					
1	Identify the grille & hardware with parts list.											
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.											
3	Identify the inserts .The longer insert is the top and the shorter insert is the bottom. If cutting the honeycomb center, remove the grille. Cut the honeycomb area out. File any rough edges smooth.											
4	Note the tabs welded to the end of each insert .Center the bottom insert in the lower opening. Mark both mounting holes in the opening. Drill a $1/8^{"}$ hole at each mark. Insert a screw at each tab and the fasten with a flat clip from the rear. Now tighten the screws.											
5	Repeat the installation of the upper insert as Step 4.											
6	Make sure the fasteners are tight. Re-install the grille assembly if needed.											
7	Installation completed!!!											

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!