

## PATENT PRODUCT Grille Installation Instruction

Rev. 20201101

Part#	N65923C&J&S		Application		For 2013-2016 Nissan Pathfinder							
	Ite	m Pa		rt Name	QTY	Descr	iption	Item	Part Name	QTY	Description	
Parts Li	π		illet Gri	rille 1		Stainless Steel		#3	Toggle Nuts	4	6-32	
	#2 Bolts			4		6-32×2"						
Install Notes: Overlay $\boxed{\hspace{1em} \checkmark \hspace{1em}}$ Replacement $\boxed{\hspace{1em} \times \hspace{1em}}$ Drill $\boxed{\hspace{1em} \times \hspace{1em}}$ Cut $\boxed{\hspace{1em} \times \hspace{1em}}$												
Step	Description illustration											
1	Identify the grille & hardware with parts list.											
2	Optional: pop hood, remove the black plastic cover (on top of OEM grille) from vehicle. If you are still unable to access the rear, remove the grille shell according to factory manual.											
3	Insert the Bolts into the weld tab hole from front side of the billet grille.  picture for reference only; this is not actual grille  Bolts  Toggle nut											
4	Center the billet grille onto the OEM grille. Press & insert the Toggle Nuts on to the rear of the OEM grille through the gap.											
(4) Toggle Nuts (4) Bolts												
5	Make sure the insert is centered and tighten the hardware.											
6	Reinsta	Reinstall the plastic shroud with the fasteners removed in Step 2.										
7	Installation completed.											

The instruction here is for your reference only. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!