

Grille Installation Instruction

Rev. 150116

| Part# | GR14FFD77H | Application | 07~09 Nissan Altima Sedan – Low Bumper Billet Grille |
|-------|------------|-------------|--|
|-------|------------|-------------|--|

| | | Item | Part Name | QTY | Description | on | Item | Part Name | QTY | Description | | |
|---|---|------|-----------------|-----|-------------|--------------|------|--------------|-----|-------------|--|--|
| Parts L | iot | 1 | Billet Grille | 1 | Aluminum | | 4 | Flat Washers | 4 | 6# | | |
| Parts L | .151 | 2 | Machine Screws | 4 | 6-32×1.5" | | 5 | L Bracket | 2 | 1/2×1/2 | | |
| | | 3 | Nylon Lock Nuts | 4 | 6-32 | | 6 | J Hooks | 2 | 1.5 | | |
| Install Notes: Overlay Variable Vari | | | | | | | | | | | | |
| Step | Description | | | | | illustration | | | | | | |
| 1 | Identify the grille & hardware with parts list. | | | | | | | | | | | |
| 2 | Remove the factory grille shell; Use a small screwdriver to pull the center from six fasteners along the top of the grille and bumper cover. Next, lightly pull the top of the grille assembly forward; use a slotted screwdriver to depress the clips on each end of the grille. Use your fingers to depress the molded clips along the bottom of the grille; remove the grille. | | | | | | | | | | | |
| 3 | Center the billet over the opening. Remove the insert. Note the tabs welded to the rear of the insert. From the front, insert a screw into each tab on the billet insert. | | | | | | | | | | | |
| 4 | Install the L brackets on the top; then thread a nut and washer on each screw. Install the J hooks on the bottom. Now place the billet insert over the opening. Wrap the brackets around the factory cross bars; tighten the hardware. Make sure the insert is centered; loosen the hardware and adjust if needed. | | | | | | | | | | | |
| 5 | Re-install the grille onto the vehicle. | | | | | | | | | | | |
| 6 | Installation completed!!! | | | | | | | | | | | |

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during

installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!