Grille Installation Instruction

Rev. 181001

Part#	GR14FFD86A/H	Application	For 2003-2008 Nissan Murano

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Fully Threaded Studs	4	10#X3″
	2	K-lock Nuts	4	10#	4	Flat tabs	2	

Install Notes: Overlay √   Replacement ×   Drill ×   Cut ×

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove any filler panels that may block access to the backside of the bumper opening.	
3	Install the fully threaded studs into the threaded tabs on the backside of the billet grille.	
4	Center the billet grille into the factory bumper opening.	
5	Place the flat tabs over the fully threaded studs and hold in place using the k-lock nuts.	
6	Make sure the billet grille is centered and tighten the fasteners, but do not over-tighten.	
7	Re-center the billet grille to your liking and secure all hardware.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
We are not responsible for any damage caused by the installation. Thank you for choosing our product!