

Grille Installation Instruction

Part#	GR14FFE09A/H		Application F		For 200	For 2008-2012 Nissan Pathfinder With Logo Show				
	Item	Part Name	QTY	Desc	ription	Item	Part Name	QTY	Description	
Parts Lis	t 1	Billet Grille	3 Aluminum		um	3	Truss Head Screws	8	8×2″	
	2	Flat Tabs	8			4	U- Clip Nuts	8	8#	
Install Notes: Overlay 🗸 Replacement 🗵 Drill 🛛 Cut 🔍										
Step	Description					illustration				
	Identify the grille & hardware with parts list.									
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.									
3	Place one screw through each of the welded tabs on the billet grille.									
4	Place a U-clip nut over each of the holes on the flat tabs.									
	Place a tab behind the grille shell in line with were the screw comes through. Tighten each of the screws evenly so as not to put the grille in a bind and not to make it go off center.									
6	Make sure the grille is centered and tighten the fasteners.									
7	Reinstall the black plastic cover which was removed in step 2.									
8	Installation completed!!!									

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!