




Grille Installation Instruction

Rev. 190801

Part#	GR14FFE21 A/H	Application	For 2008-2015 Nissan Armada
-------	--------------------------	-------------	------------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	3	Aluminum	3	Truss Head Tapping Screws	8	8×3"
2	Flat Tabs	8		4	U- Clip Nuts	8	8#	

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Center the billet grille into the opening of the factory grille shell. Secure the bolt to the threaded holes on the front of the grille. Be sure the bolts are through the OEM grille shell.	
4	Place a U-clip nut over each of the holes on the tab.	
5	Make sure the billet grille is centered and where the screws come through the grille shell, place a tab in align with the screw and tighten.	
6	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!