

Part#	GR14FFE75H	Application	08~10 Nissan Pathfinder – Low Bumper Billet Grille
-------	------------	-------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Machine Screws	2	1 1/2"
	2	J-Hooks	2	3/4"	4	Nylon Lock Nuts	2	6-32

Install Notes: Overlay



Replacement






Drill



Cut



Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove six plastic fasteners from the top plastic cover to allow access behind grille. Release four plastic clips from the bottom of the grille assembly. Release the clips that hold the outer grille shell. There are two on each side that use a flathead screw driver (1). Remove the complete grille as one unit.	
3	Center the billet into the center of bumper. From the front side of the grille, place a machine screw into the bracket welded to the grille.	
4	From the backside of the grille, place a J-hook and a nylon lock nut on the machine screw. Holding the machine screw with a screw driver, tighten the nylon lock nuts securing the J-hooks to the factory grille (2).	
		 
5	Make sure the billet grille is centered and tighten the fasteners. but do not over-tighten.	N/A
6	Re-install your factory grille and enjoy.	
7	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!