



PATENT PRODUCT

Grille Installation Instruction

Rev. 190801

Part#	GR14FFF15 C/S/J	Application	For 2008-2015 Nissan Titan
--------------	--------------------	--------------------	-----------------------------------

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
Parts List	1	Billet Grille	1	Stainless steel	3	Powder Coated Brackets	2	
	2	K-Lock Nuts	4		4	Fully Threaded Studs	4	3"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	N/A
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Install the fully threaded studs into the threaded tabs on the backside of the billet grille.	
4	Center the billet grille into the bumper opening. The billet grille will only fit the opening one way and will not even fit the pocket due to the stud location.	
5	Place the powder coated brackets over the fully threaded studs and hold in place using the k-lock nuts.	
6	Re-center the billet grille to your liking and secure all hardware.	
7	Reinstall the grille shell using the hardware saved from step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!