

## Grille Installation Instruction

Rev. 150116

Part# GR14GED13S Application 04-13 Nissan Titan 04-07 Nissan Armada (Lower Bumper)

		Item	Part	t Name	QTY	Descr	iption	Iten	n	Part Nar	ne	QTY	Description	
Parts L	iet	1 Mesh (		rille	1	1 Stainless		4		Lock Nuts		4	6-32	
Parts L	isi	2	J hook		4			5		Washer		4		
		3 Thread stud		4	4 6-32x2 "									
Install Notes: Overlay × Replacement √								Orill [	×	Cut	×			
Step	Description							illustration						
1	Identify the grille & hardware with parts list.													
2	Remove the plastic bumper shroud (at the bottom of the front bumper) from the vehicle. This will allow to access to the rear of the bumper opening.													
3	Secure the thread studs into the welded nuts on the rear of the mesh grille insert.							Stud Welded nut						
4	Cer	Centre the mesh grille insert into the bumper opening.												
4	Fasten the grille onto the bumper opening with the J hooks, washers & lock nuts							Lock Nut & washer  Stud  NOTE: This picture is for reference only, it shown how to use J hook.						
5	Re-install the plastic bumper shroud which was removed in step 2													
7	Installation completed!!!													

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!