




Grille Installation Instruction

Rev. 130930

Part#	GR14GFE75T	Application	For 2008-2012 Nissan Pathfinder
-------	------------	-------------	---------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Mesh Grille	1	Stainless steel	4	Keq Nuts	4	6-32
	2	Stud	2	6-32x 2"	5	Washers	4	
	3	Studs	2	6-32x1.5"	6	L Brackets	4	1/2"x1/2"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Remove six plastic fasteners from the top plastic cover to allow access behind grille. Release four plastic clips from the bottom of the grille assembly. Release the clips that hold the outer grille shell.	
3	There are two on each side that use a flathead screw driver (1). Remove the complete grille as one unit.	
4	Center the grille into the bumper. Thread a stud in each nut welded to the grille.	
5	From the backside of the grille, place a 1/2" L-Bracket and a 6-32 nut on to each stud (2). Make sure that the grille is centered and tighten down.	
6	Make sure the grille is centered and tighten the fasteners.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!