

Grille Installation Instruction

Rev. 200801

Part#	GR14HAJ57C		Applicat	tion]	For 2010-2012 Nissan Altima Sedan					
		Item	Part	Name	QTY	Description	Item	Part Name	QTY	Description
		1 Billet Gril		е	2	Stainless Steel	6	Lock Washers	6	M6
		_			_		_		_	

	Itelli	Fait Naille	QII	Description	пеш	Fait Naille	QII	Description
	1	Billet Grille	2	Stainless Steel	6	Lock Washers	6	M6
Parts List	2	Hex Bolts	6	M6*30	7	Extended Tab	2	
Faits List	3	Lock Nuts	6	M6	8	Truss Head Screws	4	6-32×2″
	4	Flat Washers	12	M6	9	Flange Nuts	4	6-32
	5	2-Hole Tabs	2					

Install Notes: Overlay \times Replacement $\sqrt{}$ Drill \times Cut \times

Step Description illustration

1 Identify the grille & hardware with parts list.

Start from upper piece. Open hood, remove the OEM grille and grille shell according to vehicle user manual.


2





- Test fit the billet grille as they will mount to the shell. The square stops welded to the rear of each billet need to sit on the bottom of each opening. These stops help the billet secure correctly in the openings.
- In order to prevent vehicle scratched during grille installation, tape around the grille opening on the front bumper.

Attach the extended tabs on the upper welded tabs on the rear of the billet grille with hex b bolts, lock nuts, flat washers & lock washers. And then, attach extended tabs onto the cross bar on vehicle with hex bolts, flat washers, lock washers & lock nuts.



The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our



Grille Installation Instruction

Rev. 200801

Part#	GR14HAJ57C	Application	For 2010-20	12 Nissan Altima Sedan			
6	Insert the lower weld bumper. Push the b bumper, and then fa flat washers, lock wa	illet grille to attac sten the billet gr	ch the front fille with hex bolts,	Slot on front bumper Bolt, flat washer, lock washer & lock nut Lower welded tab			
7	Now install the bottom billet. Remove the factory fasteners that retain the lower pan and remove it for lower grille hardware access.						
8	Insert a screw in each tab welded to the grille. From the rear, place a flat tab on each screw. Now thread a nut on each screw.						
9	Make sure the insert is centered and tighten the hardware. Installation completed.						

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our