




Grille Installation Instruction

Rev. 190801

Part#	GR14HEC58 A/H	Application	For 2000-2001 Nissan Pathfinder Honeycomb Style
--------------	--------------------------	--------------------	--

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	3	Truss Head Tapping Screws	4	8#x3/4"
2	Flat Nuts	4	8#					

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Remove the grille shell from the vehicle. Use a die grinder to cut the center cross bar from the grille. Make your cut where the bar meets out inner grille. Cut the small vertical bars along the top and bottom of the inner grille.	
4	Center the billet into the opening. Make the four 'L' bracket holes to the grille opening. Remove the billet and drill a 1/8" hole at each mark. Re-center the billet into the opening. Use the #8 screws and flat nuts to secure the billet	
5	Make sure the billet grille is centered and tighten the fasteners.	
6	Reinstall the black plastic cover which was removed in step 2.	
7	Installation completed!!!	

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!