

Grille Installation Instruction

Rev. 180301

Part#

GR14HED03A/H Application

n | For 2004-2006 Nissan Sentra

		Item	Part Name		QTY	Y Description		Item	Part Name		QTY	Description	
Parts Li	ict	1	Billet Grille		1	Aluminum		4	Truss Head Screws		4	6-32x1.5"	
Faits Li	ISL	2	Washers		4	6#		5	Nylon Lock Nuts		4	6-32	
		3	"J" Hook Tabs		4	/							
Install N	Note	s: Ov	verlay	\checkmark	Replacen	$nent \ \mathbf{x}$	Dri		Cut	×			
Step	Description						illustration						
1	Identify the grille & hardware with parts list.												
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.												
3	Place a screw in each mount on the billet insert. Install a "J" hook tab from the back with a lock nut and washer. Place the billet insert in the bumper opening.							Generation (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Careford) (Carefo					
4	Tighten the nuts down with the "J" hook tab catching the rear edge of the bumper cover.												
5	Make sure the billet grille is centered and tighten the fasteners.												
6	Reinstall the black plastic cover which was removed in step 2.												
7	Installation completed!!!												

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result. Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation. We are not responsible for any damage caused by the installation. Thank you for choosing our product!