


<b>Part#</b>	GR14HED13U	<i>Application</i>	<b>For 2004-2007 Nissan Armada/ 2004-2015 Nissan Titan</b>
--------------	------------	--------------------	--

	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
<b>Parts List</b>	1	'J' Tabs	4		3	Keep Nuts	4	
	2	Slotted Studs	4	10-24×2"	4	Washers	4	

**Install Notes:** Overlay  Replacement  Drill  Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Optional (for vehicles with black plastic cover under hood), Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell. If you are still unable to access the rear, remove the grille shell and reattach after installation.	
3	Screw studs inside the hole behind of billet grille.	N/A
4	Push studs past through bar of factory grille.	N/A
5	Use "J" tabs hook the shell bar and Put the stud through the tabs and screw nut on the stud after washer.	N/A
6	Repeat step 4 above for each stud of the billet grilles on the face of your factory shell.	N/A
7	Adjust stud position to make sure the grille is centered.	N/A
8	Make sure the grille is centered and tighten the fasteners.but do not over-tighten.	N/A
9	Reinstall the black plastic cover which was removed in step 2.	N/A
10	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.  
 Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.  
 We are not responsible for any damage caused by the installation. Thank you for choosing our product!