

Grille Installation Instruction

Rev. 130501

Part#	GR	GR14HED16A		ication 05~0		6 Nissan Altima Low Bumper (Not For Ser Model)					
	Item	Part Na	me	QTY	Description		Item	Part Name	QTY	Description	
arts Lis	st 1	Billet Grille insert		1	Aluminum		3	Lock Nut	4	10-24	
	2	Stud		4	10-24-1/1/4"		4	Tab	4	I	
Install	Notes: Overlay $oxed{ imes}$ Replacement $oxed{}$					Drill × Cut ×					
Step	Description						illustration				
1	Identify the grille & hardware with parts list.										
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.										
3	Secure the stud to the threaded holes on the rear of the grille.										
4	Center the grille into the opening of the factory grille shell. Be sure the studs are through the OEM grille shell.										
5	Secure grille using the lock nuts and tads from the back side of the OEM grille shell.										
6	Make sure the grille is centered and tighten the fasteners.										
7	Reinstall the black plastic cover which was removed in step 2.										
8	Installation completed!!!										

The instruction here is for your reference only. You may need to bend the billet grille bars or tabs a little bit to adjust to fit. We strongly recommend the professional installer for best result.

Please use masking tape and tape the OEM grille shell along the edge to protect your vehicle during installation.

We are not responsible for any damage caused by the installation. Thank you for choosing our product!