






Grille Installation Instruction

Rev. 180701

Part#	GR14HED39A/H	Application	For 1998-2000 Nissan Frontier
-------	--------------	-------------	-------------------------------

Parts List	Item	Part Name	QTY	Description	Item	Part Name	QTY	Description
	1	Billet Grille	1	Aluminum	2	Pop Rivets	5	1/8" × 3/8"

Install Notes: Overlay Replacement Drill Cut

Step	Description	illustration
1	Identify the grille & hardware with parts list.	
2	Pop hood, remove the black plastic cover (on top of OEM grille / front panel) from vehicle. This will allow access to the rear of the grille shell.	
3	Remove stock grille shell. Using die-grinder or razorblade, cut away inner plastic mesh to chrome ring (indicated by dashed line below). Sand down edge you have just cut.	
4	Insert billet grille from back. Drill and rivet billet grille into place through the tabs on the billet grille.	
5	Grille should look like the diagram below. Re-install stock shell to vehicle.	
6	Make sure the grille is centered and tighten the fasteners.	
7	Reinstall the black plastic cover which was removed in step 2.	
8	Installation completed!!!	N/A

The instruction here is for your reference only. You may need to bend the grille a little bit to adjust to fit. We strongly recommend the professional installer for best result. We are not responsible for any damage caused by the installation. Thank you for choosing our product!